

MY 302X
MY 304X



ENGLISH

 **SAGEM**




IN A FEW WORDS ...

Switch on

- Press .

Call

- Dial the number then press .


Answer

- Press .

Hang up

- Press .

Switch off

- Press  (long press).

Hands-free

- To communicate, press .



1



Lock and unlock the keyboard from the standby screen

- Press * then OK.

Redial last number

- Press  twice.

Make a call from a number stored in the directory

- By name: enter the first letter of the name, press , scroll down the list to find your correspondent, then press  to call.
- By location in the directory: enter the location number then press * to call.

Briefly, the functions



2


MENUS

Enter using ▲ or ▼

Navigate using ▲ and ▼

Validate using OK

Quit or return to the previous menu using C



Briefly, the menus



You have just bought a mobile phone and we congratulate you on your choice.

Your phone will allow you to use different international networks depending on the roaming agreements between the operators.

We would like to remind you that this phone is approved to European standards.

To get the most out of using your phone, we recommend that you read this manual carefully and keep it handy for future reference if needed.

WARNING

According to the configuration of the networks and associated subscriptions, certain functions may not be available (indicated by *).

If an incompatible SIM card is inserted, a message will be displayed when switching on your phone. For further information, contact your Operator.

Compatibility of your SIM card

Your phone is compatible with SIM 3V cards only.

The SAGEM logo and trademark are the property of SAGEM SA. AT is a registered trademark of Hayes Microcomputer products Inc. Hayes is a registered trademark of Hayes Microcomputer Products Inc. T9™ Text Input is a registered trademark of ©Tegic Communications Inc. T9 is licensed under one or more of the following U.S. Patents: 5,818,437, 5,953,541, 5,187,480, 5,945,928, 6,011,554 and additional patents are pending worldwide.

3

GLOSSARY

Outgoing call	A call made from your phone.
Incoming call	A call received by your phone.
SIM card	The card containing your subscription and access rights to services. The detachable part is the "micro-SIM".
PIN	The personal code linked to your SIM card.
PIN2	The second personal code linked to your SIM card to access certain functions (*).
Phone code	The phone code is a secret code intended to protect the phone in case of theft.
IMEI	The identification number of your phone.
SMS	Short Message Service: sending and receipt of text messages, icons, animated screen savers and melodies.
Service provider or Operator	Company which manages the network subscription.



1. Presentation of the phone	6	4. Menu list	17
1.1 Exchanging the coloured front panel	9	5. How to use the directory	20
2. Getting started	10	5.1 Directory display	20
2.1 Information on the SIM card	10	5.2 Storing a number	20
2.2 Installing the SIM card and the battery	11	5.3 Deleting a number	21
2.3 Charging the battery	12	5.4 Call groups	21
2.4 Switching on/switching off, starting up	13	5.5 Sorting	23
2.5 Menu access	14	5.6 Sending a short message to a stored number ..	23
2.6 Deleting characters	14	5.7 Directory space memory	23
3. Initial communication - Hands-free mode	15	5.8 Displaying personal numbers	23
3.1 Making a call	15	5.9 Making a call with a stored number	23
3.2 Receiving a call	16	6. SMS	25
3.3 Volume control	16	6.1 Receiving an SMS message	25
3.4 Hands-free mode	16	6.2 Editing a message using Easy Message T9™ ..	28
3.5 Ending a call	16	6.3 Edited messages	30
4. Menu list	17	7. How to use the call related features	31
5. How to use the directory	20	7.1 Forwarding calls	31
5.1 Directory display	20	7.2 Viewing the list of the last numbers used	32
5.2 Storing a number	20	7.3 Monitoring the duration and cost of calls	32
5.3 Deleting a number	21	7.4 Displaying the numbers	33
5.4 Call groups	21	7.5 Authorising double call	34
5.5 Sorting	23	7.6 Configuring automatic redial	34
5.6 Sending a short message to a stored number ..	23	7.7 Voice mail number	34
5.7 Directory space memory	23	7.8 Local information distribution	34
5.8 Displaying personal numbers	23	7.9 Replacing the international prefix	34
5.9 Making a call with a stored number	23	7.10 Placing calls on hold	34
6. SMS	25	7.11 Multi-conferencing (*)	35
6.1 Receiving an SMS message	25	8. How to adjust the ringing tones	36
6.2 Editing a message using Easy Message T9™ ..	28	and the vibrator	36
6.3 Edited messages	30	8.1 Selecting the volume and the type	36
7. How to use the call related features	31	of ringing tone	36
7.1 Forwarding calls	31	8.2 Call groups	37
7.2 Viewing the list of the last numbers used	32	8.3 Personalising the ringing tone	37
7.3 Monitoring the duration and cost of calls	32	8.4 Setting the vibrator	37
7.4 Displaying the numbers	33	8.5 Selecting silent mode	38
7.5 Authorising double call	34	8.6 Setting the beeps	38
7.6 Configuring automatic redial	34	8.7 Deleting DTMF tones	38
7.7 Voice mail number	34		
7.8 Local information distribution	34		
7.9 Replacing the international prefix	34		
7.10 Placing calls on hold	34		
7.11 Multi-conferencing (*)	35		

Contents



5

9. How to adjust and customize your phone 39

9.1 Customizing your phone 39

9.2 Selecting the display language 41

9.3 Select the type of response 41

9.4 Selecting the network 42

9.5 Setting the time and date 43

9.6 Controlling screen contrast 43

9.7 Converting currencies 43

10. How to use the security features of your phone 44

10.1 Locking the keyboard 44

10.2 Changing the PIN number 44

10.3 Changing the PIN2 number (*) 45

10.4 Changing the phone code 45

10.5 Changing the operator password (*) 46

10.6 Limiting incoming calls (*) 46

10.7 Limiting outgoing calls (*) 46

10.8 Setting up the pre-set directory (*) 47

10.9 Charge checking (*) 47

11. Other functions 48

11.1 Calculator 48

11.2 Setting the alarm 49

11.3 Setting the timer 49

11.4 Configure your phone with a car kit 49

11.5 Data parameters 49

12. WAP Function 50

13. Games 53

14. Available accessories 54

15. Upkeep 55

16. Recommendations 56

Answers to your questions 59



Contents



6

Antenna

Ear phone/speaker

High definition graphics screen

Programmable key 1

Correction


Stop/End call

Scrolling arrow

Microphone

WARNING!

During a call, mind you do not obstruct the microphone with your hand.



Indicator light

Programmable key 2
(depending on model)

Mobile Internet access key
Operate/Call
Activation of hands-free

Validate

Scrolling arrow





Battery charging and accessories socket

1. Presentation of the phone





Function keys

-  Stop – Reject a call – Hang up
-  Go – Call a number – Receive a call – Hands-free mode
- C** Short press: Return to the previous menu – Delete a character
Long press: Exit menu mode – Complete deletion of the entry
- OK** Validate
 - - Programmable keys for direct access to the functions that you have selected (depending on model)
 - - Volume control during conversation (• key: lower, •• key: louder)
 - Contextual action
- @** Mobile Internet access key
-  and  Entry and scrolling through the menus.



7

Alphanumeric keyboard

Made up of 12 keys: 0 to 9, * and #.

To obtain a number or letter, hold down the relevant key until the desired number or letter appears.

Letters with accents are obtained by a long press on * after entering the letter with no accent.

Punctuation marks and special symbols are obtained by a long press on the # key.

Key 1

A long press on key 1 allows you to access the voicemail service (depending on model).

1. Presentation of the phone



Display


The high definition graphics screen enables you to read messages easily. Various icons inform you about the status of functions.



Battery charge indicator (black if charged, clear if discharged)



Received signal strength indicator (maximum strength: 5 bars) ; the **R** letter indicates if the network found does not correspond to the subscription

If  flashes, the phone is searching for a network



Hands-free loudspeaker



Call in progress



Permanent call forwarding



Silent mode

8




Receipt of SMS and presence of SMS not read; Flashing: SMS memory full.



Voice messages present.

The three keys located under the screen are allocated to actions described at the bottom of the screen just above the key, each time it is necessary.

For example:

Validate Pressing  validates the current function.




1. Presentation of the phone






1.1 Exchanging the coloured front panel

- Switch off the phone.
- Remove the rear cover and the battery (see on page 11).
- Hold the phone with the front panel facing downward, and with the antenna pressed against you.
- Free the front panel by moving the retention lugs (1).




9

- Release the front panel by moving the retention lugs (2) if necessary and pushing them with a pen for example.



- Install the keyboard in the new front panel.
- Position the phone and the new front panel as shown.



- Replace the battery and the cover.

1. Presentation of the phone





10

2.1 Information on the SIM card

To use your phone, you have a small card called a SIM card. In addition to all of the information necessary for the network, this card contains other information that you can modify:

- secret codes (PIN and PIN2 - Personal Identification Number)
- directory
- mini-messages
- functioning of specific services.

SIM card

This card must be handled and stored with care in order to avoid excessive stresses or scratches that would damage it. If your SIM card is lost, contact your Operator or Service Provider immediately.
Note: Do not leave you SIM card within the reach of small children.

2. Getting started

2. Getting started



PIN code

This is the personal code for your SIM card. You may be asked to enter this code when the instruction: Pin number ? appears after you switch on your phone.

- Enter the code of between 4 and 8 digits given to you by your operator. These digits will not be displayed on the screen for security reasons.
- Press # or OK or •• to validate.

PIN2 code (*)

If one was given to you by your Operator, a second PIN code provides secure access to certain functions.

Warning

If the wrong PIN code is entered three times in a row, the card will be locked. To unlock your card:

- enter **05*
- enter the PUK code (Personal Unlocking Key) provided by your Network Operator and validate,
- enter your PIN code and validate,
- enter your PIN code again and validate.

After 5 or 10 times (depending on SIM card type), the SIM card will be permanently locked. Contact your Operator or your Service Provider to obtain a new card. The same procedure (entering 052) applies when the PIN-2 code is blocked (PUK 2 code).







2.2 Installing the SIM card and the battery

Switch off your phone and disconnect the charger.

The SIM card is inserted beneath the phone's battery.

- Turn your phone over and remove the rear cover. Press on top and make it slide.
- Slide the card along the base beneath the retaining plate, with the gold coloured sections facing towards the phone and the cut-off corner lined up to match the drawing on the phone.
- Place the battery by first inserting the upper section into the opening.
- Replace the cover sliding it until it locks.



2. Getting started




2.3 Charging the battery

Your phone is powered by a rechargeable battery. A new battery must be charged for at least 4 hours before it is used for the first time. It will reach its nominal capacity after several usage cycles.

When your battery has run down, the phone displays it and cuts out.

To recharge your battery:

- Connect the charger to a wall outlet.
- Connect the end of the charging cable to the bottom of your phone.



- The phone will start charging. The battery charging indicator indicates the charge. Charging stops by itself.
- Unplug the cable.

It is possible that during charging, the battery may heat up slightly; this is normal.

12

WARNING




- There is a risk of explosion if the battery is incorrectly replaced or disposed of in fire.
- Do not short-circuit.
- The battery does not contain any components that can be changed by you.
- Do not attempt to open the battery case.
- Only use the correct chargers and batteries as shown in the manufacturer's catalogue.
- Spent batteries must be collected at the appropriate sites.
- You are advised to remove the battery if you intend to leave your telephone unused for a long period.

2. Getting started



2.4 Switching on/switching off, starting up

To switch on your phone:


- Press  to switch on your phone.
- If access to the SIM card is protected by a secret code, the phone will ask you to enter your PIN code.

Enter the code of between 4 and 8 digits given to you when you were given your SIM card. These digits will not be displayed on the screen for security reasons.

- Press # or **OK** or •• to validate.

Control of the PIN code

If your phone displays SIM absent,


press  (long press) to switch off your phone and check that your SIM card is correctly positioned.

Searching for a network

The phone then searches for a network on which it can communicate:

- If it finds one, the name of the network appears on the screen, and the indicator light flashes green.

You are ready to make or receive a call.

- If the R letter and a network name are displayed, calls can be made and the indicator light flashes green.
- If the R letter is displayed without any network name, only emergency services will be accessible (police, ambulance, fire brigade).
- If the  flashes, the phone will keep searching. No network is available.

Network indicator




The indicator of the level of network signal received enables you to visualise the quality of reception. If it shows less than three bars, look for better reception to make your call in good conditions.

2. Getting started



14

Switching off

- Hold down the  key until the end message is displayed.
- Release the key. The phone switches off.

2.5 Menu access

The menu functions permit you to verify or modify the various functions of your phone to adapt it to your needs.

- Press the scrolling arrows ▼ or ▲ to access the menus.
- Scroll through the menus using the scrolling arrows then press **OK** to access the selected menu.
- Each time you want to validate an action, press **OK**.
- To abandon an action, press **C**.
- To exit the menu mode, press and hold **C**.

Direct access to menus

To directly access a menu, press ▼ then enter the number of the selected menu.

2.6 Deleting characters

You can cancel an entry error:

- Press quickly on **C** to delete the last character.
- If you press this key longer, you will delete the previous word.

2. Getting started



3. Initial communication Hands-free mode


15

3.1 Making a call

The network is displayed.

- Dial the number, including the area code if necessary, by pressing keys on the alphanumeric keypad.

- Press .


During the call,  flashes on the screen, and tones may signal the establishment of a connection.

- When the person you have called answers, speak.

International call

Press **0** (long press) to display + then dial the country code without waiting for a tone, then the number you require.

Emergency services

Depending on the operator, you can contact the emergency services with or without a SIM card or when the keyboard is locked. It is sufficient to be in a zone served by a network. To call the international emergency service, dial **112** then press .

Other emergency service numbers may exist, depending on the country.

3. Initial communication



3.2 Receiving a call



When you receive a call:

- Press  then speak.

The caller's number is displayed when it is presented to the network.

- All incoming and outgoing call numbers are registered in the list of the last calls.

3.3 Volume control

- Increase or decrease the volume during a conversation by pressing the  or  keys.





16

3.4 Hands-free mode

During a call, you can transfer from handset mode to hands-free mode simply by pressing one key and the reverse.

- Press .

The screen displays  for handset mode and  for « hands-free » mode.

The "Hands-free" mode enables you to follow a conversation with several people and be free to move, for example, to take notes during your conversation.

Before putting the phone to your ear, check the volume control settings as well as the selected listening method, especially if using integrated hands free mode, which could cause ear damage if used incorrectly.

3.5 Ending a call

- Press .

The end of call message appears on the screen.

3. Initial communication



17

You have the option of personalising the presentation of the menus, and so of limiting access to certain functions (See chapter How to adjust and customize your phone).

The following list presents the expert level (limiting itself to the 3rd sub-menu).

Services

Access to specific services offered by the operator

Directory

Directory menu 20

- Sort by location
- Create record
- Call groups
- Available memory
- Personal numbers
- Quit

Scroll through the names entered 23

- See record
- Modify
- Delete
- Call
- Send message
- Quit

4. Menu list

According to the model of your phone, to the configuration of the networks and associated subscriptions, certain functions may not be available (indicated by *).

4. Menus



18

Text messages

Access to the SMS 25

Call services

Call forwarding 31

- All voice calls
- All conditional fwd
- Cancel voice forwards
- Forward if busy
- Forward if no answer
- Forward if unavailable
- Data forwarding
- Faxes forwarding

View last numbers 32

- Options
- Call

Duration and cost of calls (*) 32

- Counters
- Delete durations
- Costs (*)
- Delete costs (*)
- Display of duration

Display numbers 33

- Anonymous mode
- Your number
- Callers' number

Double call 34

- Activation
- De-activation
- Status

Automatic redial 34

Voice mail number 34

Local information (*) 34

Replace "+" prefix (*) 34

Ringings and beeps

Volume and choice of music 36

Call groups 37

Personalised ringing tone 37

- Create a tune

Vibrate 37

- Vibrate and ring
- Vibrate then ring
- Inactive vibrate
- Only vibrate

Silent mode 38

Beeps 38

- Keypad beeps
- Network beep
- Low battery beep

Tones 38

4. Menus

**Controls**

Customization	39
Menu type	
Energy saving	
Screen Saver	
Greeting message (*)	
Prog. Key (*)	
Select language	41
Automatic response	41
Auto. answer	
Any key	
Network selection	42
Networks available	
Preferred networks	
Setting time/date	43
Display contrast	43
Currency converter	43
Rapid exchange	
Exchange rate	
Currencies	
Security	
Keyboard locking	44
PIN number	44
Modify	
Control PIN	
PIN2 number (*)	45
Phone code	45
Modify	
Control phone code	

Operator password (*)	46
Limit incoming calls (*)	46
Incoming voice calls	
Incoming data calls	
Incoming fax calls	
All incoming calls	
Limit outgoing calls (*)	46
Outgoing voice calls	
Outgoing data calls	
Outgoing fax calls	
All outgoing calls	
Pre-set directory (*)	47
Costs (*)	47
Settings	
Limitation	

Accessories

Calculator	48
Alarm	49
Timer	49
Car kit (*)	49
Data parameters	49

Games**4. Menus**






20

5.1 Directory display

You can store the telephone numbers that you call regularly:

- in the SIM card,
- in the phone itself.

Different icons will inform you of the directory location where the number is stored when you search for it:

-  SIM card directory
-  Your phone's directory
-  SIM card pre-set directory.

The number of telephone numbers stored in the SIM card directory varies depending on the capacity of the card. Your Operator or your Service Provider can provide you with this information.

5. How to use the directory

5.2 Storing a number

- In the **Directory menu**, select **Create record**. Validate by pressing **OK**.
- Enter the name (the number of accepted characters depends on the SIM card used). Validate.
- Enter the number including the area code, if necessary (up to 20 characters). Validate.

It is advisable to store numbers in their international format (+, country code, and number). You can verify the contents of a record and modify it by selecting the required name.

5. Directory



21

You can enter spaces in the number (displayed as commas “,”) by pressing (long press) on * or #. The figures entered after a space are processed in a DTMF sequence (usable after a number).

- If necessary, select the call group to which you want to assign this number.

Depending on the available space, you can select the storage location of the number entered: SIM card or phone itself.

When sorting by location, pressing on the * key launches a search for the first available location; pressing on # returns to the start of the list.

Creating a group

By default, groups have already been created in the phone.

In order to look up their characteristics, display a list of the groups - **Directory/Directory menu/Call groups** menu.

Using the scrolling arrows, choose a group and press **OK**. You are then able to look up or alter its characteristics or to erase the group.

To create a new group:

- Go into **Directory/Directory menu/Call groups**.
- Choose **Create group**.
- Enter a name and validate.
- Choose an icon using the scrolling arrows and validate.
- Choose a ring tone, then choose a vibrator mode, and validate.

The selection of a call group is made when entering a number into the directory, or when modifying a number you have already saved.

5.3 Deleting a number

To delete the contents of a directory location, select the name using the scrolling arrows. Validate by pressing **OK**. Select **Delete**, then validate.

5.4 Call groups

You are also able to classify contacts recorded in the directory into Call Groups.

To each of these groups you attribute certain characteristics (icon, ringing tone, vibrator, etc.).

5. Directory



Activate the Call Groups function

If you want the characteristics of the groups to apply to each call:

- Go into **Directory/Directory menu/Call groups**.
- Choose **Activate groups**.
- Tick the box and validate.

The calls received from contacts who do not belong to a Call group use the parameters provided in the Ringing and beeps menu.

Available memory

To ascertain the number of groups which can still be created:

- Go into **Directory/Directory menu/Call groups**.
- Choose **Available memory**.

The first number shows the number of groups which can still be created, and the second shows the maximum number of groups.

If call groups are not enabled, you cannot attach correspondents to groups.

Looking up a group

- Select the group to be looked up and press **OK**.
- Choose **See group**. The screen presents the name, the icon, and the choice of vibrator mode of the group.
If there are contacts attached to this group, press the **••** key can be used to view the list of these ones.

Modifying a group

- Select the group to be modified, and press **OK**.
- Choose **Modify**.
- Carry out the wanted modifications.
- Validate by **OK**.

Deleting a group

- Select the group to be deleted, and press **OK**.
- Choose **Delete**.
- Confirm by **OK**.



5.5 Sorting

Directory menu enables you to sort the stored numbers by name or location; for the latter, the free locations are indicated in the list.

5.6 Sending a short message to a stored number

- Select the recipient scrolling using the scrolling arrows and validate using **OK**. Select **Send message** and validate using **OK**.
- Compose your text message.
- Press **OK**. Select **Send** and validate using **OK**. The recipient number is displayed.
- Send your message using **••** key.

5.7 Directory space memory

- In **Directory menu**, select **Available memory**. Validate using **OK**.
- The screen will display the amount of available space on the SIM card and on the phone itself.



5.8 Displaying personal numbers

- Using **Directory menu/Personal numbers** menu, you can create records for your own numbers in order to be able to consult them.

5.9 Making a call with a stored number

Here are all the ways you can call a correspondent, whose number you have saved in the directory, from the standby screen:

- 1) Enter the first letter(s) of your correspondent's name, as you saved it into the directory, and then press


The directory list is displayed, with the first name that corresponds with the letter you entered at the top. If your correspondent is not at the top, use the scrolling arrows to select the name.

Press on to make the call.

5. Directory



24

- 2) Enter the number under which you have saved your correspondent's details, and then press on * (rapid dial).
- 3) Enter the number under which you have saved your correspondent's details, and then press on #. Your correspondent's number is displayed, at which point you can modify or add to the number.
Press on  to make the call.



5. Directory





25


6.1 Receiving an SMS message

Several types of SMS messages can be received:

- text messages
- icons for call groups
- animated screen savers
- melodies
- WAP bookmarks.

Access to this service depends on the network. For more information, consult your Operator or your Service Provider.

6. SMS

When you receive an SMS message, a beep is heard, (the beep selected in the menu Ringing and beeps/Volume and choice of music/Messages) a flashing red light appears and the  icon is displayed on your phone screen.

This icon remains on screen as long as the SMS messages have not been read.

When the memory flashes, it is full.

6. SMS



The receipt of icons, animated screen savers or melodies can take several minutes. Messages inform you of the downloading progress.

You can hide that screen at any time by pressing • (e.g. to make a call or access other information on your phone) or delete the download in progress by pressing ••.

Go into the **Text messages** menu to access the list of messages received.





Ask your Operator about the downloading of SMS icons, animated screen savers or melodies.

Unread SMS messages are in bold.



This symbol indicates that an SMS message has been altered: it consists of several fragments, some of which have been deleted.




Meaning of the symbols in front of each SMS message

-  Call group icons
-  Animated screen savers
-  Text messages
-  Melodies.

Actions possible on an SMS message received

- Select an SMS message.
- By pressing ••, you can:
 - read an SMS text message
 - view and save an SMS icon or animated screen saver
 - listen to and save an SMS melody.
- When you press • (**Options**), various options are available according to the type of SMS message received:
 - read it
 - delete it

Meaning of the symbols at the top of the screen

-  This symbol indicates a written text message. If this symbol is flashing, it means that the SMS message has not been sent.
-  This symbol indicates an SMS message received. If this symbol is flashing, it means that the SMS message has not been read yet.
-  This symbol indicates an SMS message which is incomplete or in the process of being downloaded.

6. SMS



- reply
- forward it to another person
- consult the available memory
- delete all SMS messages already read
- delete all SMS messages
- choose a sending option
- enter the number of the messaging centre
- add a WAP bookmark (see below)
- save it in your phone (SMS melody, animated screen saver and icon (see below)).

Warning

Only the screen savers and melodies without Copyright may be forwarded to another person and depending on model.

27

Saving a melody in your phone

A melody is saved in the **Ringing and beeps/Personalised ringing tone** menu.

- If you have just listened to it, press •• (**Record**)

or

- Select it in the list and choose the **Save** option by pressing • (**Options**).

The space required as well as the space available in the phone are indicated.

If the maximum number of melodies or the maximum capacity has been reached, you will be asked if you wish to delete some melodies or replace an existing melody with the new one.

- ✓ This sign placed in front of a melody indicates that it can be deleted and will free enough memory space to save the new one.
- ⊖ This sign placed in front of a melody indicates that it can be deleted but will not free enough memory space to save the new one.

Warning

You must listen to the entire melody in order to be able to save it.

Adding a WAP bookmark in your phone

To add a WAP bookmark received:

- If you have just read it, choose the **Add WAP bookmark** option by pressing • (**Options**)
- or
- Select it in the list and choose the **Add WAP bookmark** option by pressing • (**Options**).

6. SMS



Saving an animated screen saver on your phone

An animated screen saver is saved in the **Controls/Customization/Screen Saver** menu.

- If you have just viewed it, press **•• (Record)**
or
- Select it in the list and choose the **Save** option by pressing **• (Options)**.

Warning

You must view the entire screen saver in order to be able to save it.

The space required as well as the space available in the phone are indicated.

If the maximum number of animated screen savers or the maximum capacity has been reached, you will be asked if you wish to delete some animated screen savers or replace an existing one with the new one.

Saving an icon in your phone

An icon is saved in the menu **Ringing and beeps/Call groups/Call groups** menu.

- If you have just viewed the icon, press **•• (Record)**
or

28

- Select it in the list and choose the **Save** option by pressing **• (Options)**.

The space required as well as the space available in the phone are indicated.

If the maximum number of icons or the maximum capacity has been reached, you will be asked if you wish to delete some icons or replace an existing one with the new one.

6.2 Editing a message using Easy Message T9™



The Easy Message T9™ function helps you to easily enter short messages.

Select the **Text messages/Write new...** menu and press **OK**.

Selecting the editing language

- Validate T9 by pressing the **••** key. Select using the scrolling arrows, the language required and validate by pressing **OK**.

T9™ mode is activated as soon as you create or modify a message.

Language

By default, the language used is that which is activated on the phone's menu display (or English if a language not supported by Easy Message T9™ is selected in the menu).

6. SMS



Using T9 mode

- Press the key corresponding to the letter required, compose the word by continuing to press the keys corresponding to the different letters, without worrying about the display, until the whole word is entered: it will appear in negative, white on black.
- If the word proposed corresponds to the one you are looking for, press **0** to validate it, create a space and go on to the next word.
- It is possible that there are several words in the dictionary that contain the same sequence of keys pressed. If the word that appears is not the one you want, press **@** to scroll through the words present in the dictionary, corresponding to this sequence of keys. When you find the word you want, press **0** to validate, type a space and go on to the next word.
- If the word that you want does not appear in the dictionary, several additional modes allow you to vary the nature of the words entered.

As you go along, depending on the keys pressed, the software looks in a dictionary for the corresponding words that are most frequently used.

29

Additional entry modes

- The key **••** selects one mode or another.
- The **123** mode inserts numbers.
- The **Insert symbol** mode displays a list of symbols and the figures from 0 to 9 that correspond to them.
To enter a symbol, simply type the number that appears above the character required, for example: 6 for ?. The symbol is inserted into the text and you return automatically to Easy Message T9™ mode. Several lists are accessible using the scrolling arrows.
- The **ABC** mode enters words that do not exist in the dictionary or in another language. To obtain a letter, hold down the corresponding key. The letters and numbers scroll. Release the key when the required letter appears.

Capital letters

- You can type capital letters, by pressing the ***** key before entering the relevant character. The following characters will automatically return to lowercase.

6. SMS



Words in capital letters

- You can also choose to type a whole word in capital letters by pressing twice on the * key before entering the word. It is possible to return to lower case mode by pressing once on the * key.

Punctuation marks

- Punctuation marks are obtained by using either the 1 key (except in numeric mode), or using the Insert symbols mode (quick access using # key).

Accented characters

- Accented characters are automatically generated in the word in Easy Message T9™ mode. In ABC mode, you need to wait for the accented character to be displayed whilst holding down the corresponding key.

The number of messages stored in the SIM card changes depending on the SIM card capacity; contact your Operator or your Service Provider for further information.

30

After validating your text, you can choose one of the following options:

- Send your message
- Store your message
- De-activate Zoom
- Cancel.

6.3 Edited messages

Pressing the key • (Options), different options are available for an edited message:

- read it
- send it
- delete it
- modify it
- view the memory occupation level
- delete them all
- select a send option (acknowledgement, reply given, period of validity, message format)
- enter the message centre number.

6. SMS



7. How to use the call related features

31

7.1 Forwarding calls

Forwarding voice calls

Depending on your subscription, this service allows you to transfer incoming calls to another number or a mailbox.

Look out for incompatibilities; for more information, consult your Operator or your Service Provider.

- Scroll through the menu to activate the type of forwarding that you require:
 - Forward all voice calls: all incoming calls are forwarded to a number you define
 - Forward all conditional calls
 - Forward calls when your line is busy
 - Forward calls when there is no answer on your extension after a period that you can define by answering the questions on the menu
 - Forward calls when your phone is unavailable, outside of network coverage or switched off.
- Enter the number to which you want to forward your calls. If necessary, include the area code you would use if you were calling the number from your phone.

7. Call related features



- Validate by pressing •••
A message on the screen confirms that forwarding has been activated.
- You can also cancel all types of forwarding.
- You can view the status of a type of call forwarding in order to verify whether it is active or not. This function is also useful for controlling the number to which your calls are forwarded. The information supplied is provided by the network.

The forwarding number to the messaging centre depends on the subscription type.

Warning

Cancellations of forwarding can cause particular reactions in certain networks.

Forwarding data or faxes

Depending on your subscription, this service permits you to transfer data or faxes that are addressed to you to another number.

You can activate the data or faxes forwarding service, to enter the required number, cancel it and view the status of the service.

For services specific to a network, such as mailboxes, short dialling is only valid when covered by the particular network. You may possibly prefer an international number. This memory is linked to the phone and not to the SIM card.


7.2 Viewing the list of the last numbers used

You can consult the list of the last numbers used (outgoing and incoming if available).


Several options are available for this number: store it in your directory, send it a short message, delete it. You can also delete the whole list of numbers.

To redial a number:

- Select from the list using the scrolling arrows.

Make the call by pressing on .

- Shortcut

From the standby screen, press on .

7.3 Monitoring the duration and cost of calls (*)

- On the **Counters** menu you can view the duration of the last call and all calls made since the last deletion.
- The **Delete durations** menu enables you to delete the duration of the last call and reset to zero the total calls counter.

7. Call related features





33

■ On the **Costs** (*) menu you can view the cost of the last call and all calls made since the last deletion.

■ The **Delete costs** (*) menu enables you to clear the cost of the last call and to reset the call counter after entering your PIN2 code.

■ The **Display of duration** menu enables you to select the duration display during a call.

This data is purely indicative and does not represent proof. The metering criteria for the network can be appreciably different (indivisible minutes, etc.).

- **Yes:** you wish to use the anonymous mode and the person you are calling cannot know your number.

Your number

- On outgoing calls you can check that your phone number is displayed on the phone of the person you are calling (CLIR).
- On incoming calls, you can check that the telephone number of a phone to which you are transferring calls will appear on the phone of a person calling you (COLR).

Callers Number

- On outgoing calls, you can see the phone number to which your call is being transferred (COLP) if the person you are calling has authorised his or her identity to be displayed by deactivating the COLR option.
- On incoming calls, when it is activated, this function displays on your phone the phone number of the person calling (CLIP). This function is only possible if the caller has authorised his identity to be displayed by deactivating his CLIR option.

7.4 Displaying the numbers

This menu permits you to see the status of the display numbers function for:

- your identity (phone number)
- the identity of the person calling you.

Anonymous mode

You can decide whether the person you are calling is given your phone number or not.

- **Preset:** the phone network default mode.
- **No:** you do not wish to use the anonymous mode and the person you are calling will know your number.

7. Call related features



7.5 Authorising double call

(Service depending on the operator)

During a call, a special tone can inform you that another caller is trying to reach you. The caller's number - and name, if stored - is displayed on the screen.

During a call, when pressing the @ key, the • key changes function and gives access to different possibilities of actions with this call.

Call waiting

You can activate, deactivate and view the status of the call waiting service in order to check whether it is active or not.

7.8 Local information distribution

This menu allows you to activate and select reception of information distributed by the network.

Contact your operator for further details)

7.9 Replacing the international prefix

(Depending on model)

In the event that a call is not possible with the "+" prefix, you have the option of choosing a replacement prefix with no need to change the number(s) already recorded with the prefix + in the directory.

7.6 Configuring automatic redial

You can activate automatic redial either by default or on demand.

7.7 Voice mail number

To program a special permanent call number, type in this number and validate.

This number is used when calling the voice mail centre with the programmable keys.


7.10 Placing calls on hold

(Service depending on the operator)

During a call, you can put the current call on hold by pressing **Ok**.

Warning

During a call, when pressing the @ key, the • key changes function and enables you to access different options for the call.

In this case, pressing  ends all calls.

7. Call related features



7.11 Multi-conferencing (*)

(Service depending on the operator and depending on model)



A multi-conference is limited to 6 participants: 5 in a multi-conference and one additional call

During a call, when pressing the @ key, the • key changes function and gives access to different possibilities of actions with this call.






Multi-conferencing enables you to talk to several callers (depending on the network capacity and on the model).

Standard commands


Sequences of standard keys also permit access to services such as call notification, call holding, multi-conferencing, and open up additional possibilities:

- 0  Reject a call holding or waiting (or multi-conference calls).
- 1  End the current call holding or waiting (or the multi-conference calls if there are any) and accept the call (or multi-conference calls).

35

- 1 X  End the current call order number X.
- 2  Place on hold the current call (or multi-conference calls) and accept the call holding or waiting (or multi-conference calls).
- 2 X  Place on hold the multi-conference calls except for the current call order number X (private call).
- 3  Add a call holding (or multi-conference calls) to the current call (or to the multi-conference).
- Tel N°  Place on hold the current call (or the multi-conference calls) and call another phone number.

If you use this feature, we recommend that you first place the current caller on hold, then dial the new number as a courtesy to your caller and to ensure privacy with the other party if desired.

-  End all calls except for a possible call waiting.

7. Call related features




36

8.1 Selecting the volume and the type of ringing tone

You can set your phone to ring on receiving calls and/or short messages.

There are numerous tunes available (including a «silent ringing tone») and several volume levels including a crescendo.

- You can, during adjustment, listen to the melody selected or not: activate or don't by pressing @; the symbol  appears barred or not.
- Select the ringing tone required using the scrolling arrows.
- Press •• to move on to the next section.
- Select the volume required for using the phone with the scrolling arrows (from 1 to 4 and + for the volume crescendo) and validate using **OK**.
- Press •• to move on to the next section.
- Select the volume required for using the hands free car or pedestrian kit with the scrolling arrows (from 1 to 4 and + for the volume crescendo) and validate using **OK**.

8. How to adjust the ringing tones and the vibrator

8. Ringing tones and vibrator



8.2 Call groups

See chapter **How to use the directory** for all the functions about call groups.

Downloaded icons

If you have saved icons received by SMS (see **SMS** chapter), they will appear in the menu **Ring and beeps/Call groups/Call groups menu**.

If you select an icon in the list, it will appear at the top of the screen.

You can then delete it or select one of the following options:

- change its title
- consult the available memory
- delete the selected icon
- delete all saved icons.

8.3 Personalising the ringing tone

You have the option of creating a personalised call tune. A help menu, accessible by pressing **••**, will guide you.



37

If you have saved melodies received by SMS (see **SMS** chapter), they will appear in that menu.

You can then modify it (if the copyright allows it), listen to it or select one of the following options:

- change its title
- send it by SMS to another person (if it is not Copyright protected)
- consult its memory capacity
- consult the available memory
- delete the selected melody
- delete all melodies.

8.4 Setting the vibrator

Wherever you require your calls to arrive discreetly, you can use the vibrator or select the silent mode.

- Using the scrolling keys, select one of the following options: inactive vibrate, only vibrate, vibrate and ring, vibrate then ring.
- Validate by pressing **••**.


8. Ringing tones and vibrator



38

8.5 Selecting silent mode

If you want the ringing tone of your phone to be replaced by the vibrator and the beeps to be suppressed (except for the alarm tone), tick the box and validate by pressing **OK**.

This mode is indicated by the symbol  on the screen saver.

Silent mode is automatically deactivated when the hands free kit car is connected as well as when the phone is switched on/off.

8.6 Setting the beeps

Different controls are available:

Setting the keypad tones

- Select the tone required using the scrolling arrows and validate (press **••**).

Setting the network tone

If you want your phone to give a warning beep when it locates a network on which it can communicate:

- Tick the box and validate by pressing **OK**.

You can select the tones produced by your keypad: Beep, DTMF (musical keys) or non active tones (in this last case, when you press your keyboard, it does not make a noise).

Setting the low battery tone

If you want your phone to give a warning beep when your battery is low:

- Tick the box and validate by pressing **OK**.

8.7 Deleting DTMF tones

(Depending on model)

You can delete the emission of DTMF tones during a call. You can thus make a call, in a comfortable and discreet way for you caller.

- To be discreet, clear the selection from the box. Validate by pressing **OK**.

8. Ringing tones and vibrator



9. How to adjust and customize your phone

39

9.1 Customizing your phone

Menus type

You have the option of personalising the presentation of the menus, and so of limiting access to certain functions.

Three levels are available:

- **Expert**: presents all of the functions
- **Essential**: presents the main functions
- **Restricted**: limits access to certain functions.

Installing the energy saving mode

In order not to use the phone's screen light and thereby increase its operating time:

- In the **Customization/Energy saving** menu, check **No light** and press **OK** to validate.


9. Phone adjustment



Configuring the idle mode

You can choose between an animated idle screen or the economy mode.

- In the **Customization/Screen Saver** menu, use the scrolling arrows to select the animation you want, a text, a banner or the economy mode.
- Press **••** to access the setting of the animation or economy mode activation interval.
- Press **OK** to validate.

To exit the economy mode, press .

If you have saved animated screen savers received by SMS (see **SMS** chapter), they will appear in that menu.

The following options are available according to the type of screen:

- validate the animated screen savers as default screen
- change its title (only downloaded screens)

The frequency of display of the screen saver has a direct impact on the phone's operating capacity. For optimal operating capacity, set the maximum interval.

40

- consult its memory capacity
- consult the available memory
- delete the selected screen
- delete all screens.

Personalising the welcome screen

Depending on model

You can personalise the welcome screen of your phone by typing a text. Validate by pressing **OK**.

Customizing the programmable keys

Depending on model

This menu, accessible directly by a short press on a programmable key from the standby screen, enables you to configure the **•** and **••** keys. There are different possibilities for each of the keys:

The action allocated to a programmable key is triggered by a long press or two short presses only from the standby screen.

Directory

- Validate Directory.
When you press the key, you can see the names in the directory.

9. Phone adjustment



Rapid dial

- Select a name from the directory and validate. When you press the key, you will automatically call the name selected.

Silent mode

- Validate Silent mode. The ringing tone of your phone will be replaced automatically by the vibrator and all the beeps will be suppressed (except for the alarm).

Silent mode

This mode, indicated on the screen saver, is automatically deactivated/activated when the hands free kit is connected.

Call voice mail

- Validate Call voice mail. When you press the key you will automatically call your mailbox number.

Text messages

- Validate Text messages. When you press the key you can read the short messages stored in the SIM card or in the phone itself.

View calls

- Validate View calls. When you press the key, you can view the list of the last calls made and received if available.

9.2 Selecting the display language

You can select the language in which you wish your phone display to operate:

- Automatic selection. The display language will be that of your SIM card (if available).
- otherwise select the language of your choice using the scrolling arrows and validate by pressing **OK**.

9.3 Select the type of response

You can reply to a telephone call:

- either automatically, if you have ticked the **Automatic ans.** box (for a hands free kit) and validated by pressing **OK**.
- or by pressing any numeric key if you have ticked the **Any key** and validated by pressing **OK**.

9. Phone adjustment



9.4 Selecting the network

Every SIM subscription card can store an ordered list of preferred networks.

- If the list has not been programmed, or if none of the networks on the list are available or authorised, the phone searches for an authorised network providing the highest level of signal.
- If none of the available network is authorized, you can use your phone to make emergency calls only until a network connection can be re-established.
- If no network is available, your phone continues to search for one.
- In all cases, the phone searches for its home network first.

Network

When your home network is not accessible (abroad, for example), your phone automatically searches for another available and authorised network in the order of preference indicated by the list on the SIM card.

42

Available networks

This menu enables you to start a search for all available networks at the present location and to display them.

- Use the scrolling arrows to scroll the available networks and validate the one wanted (press ••).

Depending on model, you can choose a manual selection for a network search. A triangle appears in the antenna above the network icon to indicate the manual search.

Preferred networks

To program a list of preferred networks into your SIM card:

- Use the scrolling arrows to select from the list.
- Validate.

If the network is not on the list, select the country code then the network code (ask the organisation from which you obtained the SIM card).

9. Phone adjustment



9.5 Setting the time and date

Setting time/date/**Control** menu

- Set the hours and minutes by pressing on the corresponding numbers or by scrolling through the values using the ▼ or ▲ arrows.

Press ●● to go to the next setting.

- Set the day, month and year.
- Press **OK** to validate.

Setting time/date/**Display** menu

- Use the scrolling arrows to select the type of clock to be displayed on the screen or to display no clock. Press **OK** to validate.

9.6 Controlling screen contrast

- Control screen contrast using the scrolling arrows, and validate by pressing **OK**.

9.7 Converting currencies

This menu enables you to convert one currency into another. Using the scrolling arrows, you can select:



43

Rapid exchange

- If you tick the **Rapid exchange box**, the converter will operate on the standby screen, enter the digits required and use the scrolling arrows to perform a conversion.

Exchange rate

- Enter the conversion rate corresponding to the two selected currencies.

Currencies

- Enter the symbols of the two currencies to convert. A long press on **C** returns to the beginning of the line to enter them (if the symbols are already entered).



9. Phone adjustment





10. How to use the security features of your phone

10.1 Locking the keyboard

Locked keyboard

This menu enables you to lock your phone's keyboard to prevent calls from being made unintentionally in your bag or pocket.

You can still make emergency calls and answer calls.

- Tick the **Lock** box: the keyboard will automatically be locked.
- To unlock your keyboard: Press ***** then **OK**. After unlocking, the keyboard will be locked after a certain period.

For a quick keypad locking, press ***** then **OK** from the standby screen.

10.2 Changing the PIN number

Warning

You can change your PIN number:

- To the question: **Old pin number ?**, enter your old PIN code and validate (press **••**).
- To the question: **New pin number ?**, enter your new PIN code (a number between 4 and 8 digits) and validate by pressing **OK**.

If the wrong PIN code is entered three times in a row, the card will be locked. To unlock your card, call the organisation which issued your card for guidance in unlocking it. If your SIM card is permanently locked, contact your Operator or your Service Provider to obtain a new card.



- To the question: **Verify pin number ?**, enter your new PIN code a second time to verify and validate by pressing **OK**.

Checking the PIN number

You can activate your PIN number so that it is requested and checked every time the phone is switched on, so that if the phone is lost or stolen, your SIM card cannot be used:

- To the question: **Pin number ?**: enter your PIN number and validate (press **••**).
- Tick the box **Pin number cont** and validate by pressing **OK**.

10.3 Changing the PIN2 number (*)

You have a second PIN number. The procedure for modifying the PIN2 number is identical to that for the PIN number.

10.4 Changing the phone code

The **phone code** menu enables you to activate the phone code so that it is requested and checked each time the phone is switched on, in the case of a different SIM card being used.



45

If the incorrect code is entered, the time interval between each attempt increases, making use impossible.

To change the phone code, you must first check that it is active (**Control phone code** menu).

To activate:

- To the question: **Phone code?**, enter 0000 and validate (press **••**).
- Tick the **Telephone contr** box and validate by pressing **OK**.

To deactivate:

- To the question: **Phone code?**, enter your code (possibly changed) and validate (press **••**).
- Do not tick the **Telephone contr** box and validate by pressing **OK**: it will reset the code to 0000.

Once the phone code is activated, you can modify it:

- To the question: **Old phone code?**, enter your old phone code and validate (press **••**).

The phone code is a secret code, intended to protect the phone in the event of theft. It is linked automatically to the SIM card present on activation.



- To the question: **New phone code?** enter your new phone code (a number of between 4 and 8 digits) and validate by pressing **OK**.
- To the question: **Verify phone code** enter your new phone code a second time to verify it and validate by pressing **OK**.

10.5 Changing the operator password (*)

You have an operator password. The procedure for modifying this password is identical to that for your PIN code.

10.6 Limiting incoming calls (*)

Depending on your subscription, this service enables you to restrict certain types of incoming calls.

- If you have this service, you will have been provided with a password when you subscribed. This password is necessary to activate this function.

Access to this service depends on your subscription type. For more information contact your Operator or Service Provider.

46

- You can activate, deactivate, and view the status of the type of call barring. You can also cancel ALL types of barring.

The restriction can apply to ALL incoming calls or to incoming calls when you are not in your home country (if you have roaming).

10.7 Limiting outgoing calls (*)

Depending on your subscription, this service stops certain types of outgoing calls being made from your phone.

- If you have this service, you will have been provided with a password when you subscribed. This password is necessary to activate this function.
- You can activate, deactivate, and view the status of the type of call barring. You can also cancel ALL types of barring.

Access to this service depends on your subscription type. For more information contact your Operator or Service Provider.

The restriction can apply to ALL outgoing calls, to all your INTERNATIONAL outgoing calls or to outgoing international calls EXCEPT those sent to your HOME country.





10.8 Setting up the pre-set directory (*)

The pre-set directory allows you to limit calls. When you activate this directory, only the numbers you store in this directory can be called.

Before creating it, you must first activate it:

- Display the **Pre-set directory** menu.
- Enter your PIN2 number.
- Tick the **Pre-set directory** box.
- Validate by pressing **OK**.

To create the pre-set directory, proceed as you would proceed for another directory (see chapter How to use the Directory/Storing a number).

10.9 Charge checking (*)

The **Settings** menu allows you to select the type of charge indication after entering your PIN2 code:

This directory is linked to the SIM card. Thus, its size is determined by limitations of this card.

47

- Currency: enter the currency name (maximum 3 characters) and charge per unit. Ask your operator for this value.
- Telephone unit.

The **Limitation** menu allows you to activate the credit function in the selected currency after entering your PIN2 code.

Warning

These functions depend on the ability of the network to send charge data to your phone in real time, and on the capacity or options on your SIM card.



10. Security





48

11.1 Calculator

You can operate the calculator using the following keys:

••	Add
@	Subtract
*	Multiply
#	Divide
OK	Equals
C	Delete

Long press on:

* or # or @ or ••
••

Decimal point

Monetary operations if there is no calculation in progress
(See chapter **Phone adjustment**, § 9.7).

Monetary conversion.



From the standby screen, you can convert a currency into another according to the settings chosen (calculator key ••) or menu (**Controls/Currency converter**).

11. Other functions


11. Other functions



11.2 Setting the alarm

To use your phone as an alarm clock:

- Using the numbers or the scrolling arrows, set the alarm time.
- Press **••** to go to the next item.
- Set the minutes.
- Tick the box and validate by pressing **OK**.

The alarm function is represented on the screen by the symbol . Permanent flashing of this symbol indicates that an alarm time has been programmed but the date and time clock has not been initialised.

The ringer is stopped by pressing any key; the alarm remains programmed.

The alarm function remains active when the phone is switched off. It is not affected by silent mode.

11.3 Setting the timer

The same procedure is applied as for the alarm function, but in this case you start a time clock running against a defined value. The phone must remain switched on.

11.4 Configure your phone with a car kit

(Depending on the model)

As regards the phone, there are several options:

Programming the switch-off delay on your phone

- Set the phone off delay using the numbers or scrolling arrows.
- Press **••** to go to the next item.
- Tick the box and validate by pressing **OK**.

To use your phone with a hands free kit, see the notes supplied with the kit.

This delay starts counting down as soon as the end of a call is detected.

Programming the alarm timing

You can be notified that your phone is ringing when you are not in your car.

- Set the delay after which an external warning is set off using the digits or scrolling arrows.
- Tick the box and validate by pressing **OK**.

This can only happen when the vehicle is not running.

11.5 Data parameters

You can set the serial link speed when using AT commands.

11. Other functions



12. WAP Function Mobile Internet

WAP: Wireless Application Protocol – This is a protocol which converts Internet language into the language which can be understood by a mobile telephone.

The WAP browser is licensed from:



The WAP browser remains the exclusive property of Phone.com. It is therefore highly prohibited to modify, translate, reverse engineer, de-compile or disassemble the Phone.com browser or any part thereof.

50

From the standby screen, press on the **@** key to access the local menu for WAP functions.

Home: connection to the home page.

Bookmarks (depending on model): from the standby screen, following a number key with the **@** key initiates access to the favourite corresponding with the number.

You can receive bookmarks by SMS and add them to this list (see **SMS** chapter). You can also send some by SMS: select a bookmark, press **• (Options)**, then select **Send by SMS**.

Go to URL (depending on model): this menu enables you to directly enter an Internet address.

Advanced...: access to the sub-menus:

- **Connection settings** which allow you to set the parameters for several access providers (depending on model). The current access service has a star in front of it.

Depending on model, scrolling menu **0** allows you to access the WAP function.

This menu enables you to record a directory of Internet site names and addresses for easy and fast access.

All of the information to be entered in the settings is supplied by your Operator or Service Provider.

12. WAP Function



Configuration of WAP parameters

- Select the desired access service using the scrolling arrows then press on **Modify** (• key).
- The parameters to be entered are:
 - the name of the service,
 - a user name,
 - a password,
 - the IP address of the WAP gateway: enter the IP number using the @ key (**Next**) then choose **Secure** or **Non secure**,
 - the call number,
 - the access mode (digital or analog).
 Once all the parameters entered, you can activate the selected service.
- Confirm your choice with **OK**.
- **Show URL** which presents the current Internet address.
- **Disconnect** which ends the communication (allows a navigation without being connected).
- **Linger timer** enables you to set a time limit, after which the phone will disconnect automatically if you have forgotten to disconnect from a service.

51

- **FastW@p** (depending on model) which provides quicker access to the pages of Internet sites.

Reset cache: empties data stored from previous connections.

Quit: return to the phone standby screen.

The ▼ icon enables you, by pressing the @ key, to access two display modification possibilities:

- the zoom to change the size of characters by pressing on • successively
- full screen display by pressing on ••.

Connection

- From the **Home** menu, start up connection to a service.
- Once connected to a service, press on ▼ then [Menu] to return to the local menu.

When connecting on the GSM network, the @ character flashes, and the cost of communications starts to clock up as soon as it stops flashing.

12. WAP Function



52

Disconnection

- Disconnection is achieved by pressing on ▼ then [Menu] and then by using the **Advanced...** menu and **Disconnect**.

The @ character disappears from the screen.

You will be automatically disconnected after a short pause if you have forgotten to disconnect from a service.

Exit from the WAP function

To exit from the browser and end the current communication (if necessary):

- press .

or

- from the local menu, select **Quit** and validate by pressing **OK**.

12. WAP Function



53

Depending on the model, several games are available. The presentation menu guides you on how to best use them.

13. Games



13. Games



54

Depending on the model, different accessories are available on your phone:

- Additional batteries
- Additional chargers
- Desk charger
- Cigarette lighter adapter
- Hands-free kits
- Coloured front panels.

Warning

Do not connect/disconnect the special socket on your phone during a call.
The use of the EXTERNAL SIGNAL function to activate the lights on a vehicle or the horn, in order to take a call on a public road, may not be authorised.

14. Available accessories

14. Available accessories



55

Upkeep

Clean your phone using a soft slightly damp non fluffy cloth.

Battery

After a long period of non use (several months), when the charger is being connected, the unit might not switch on.

In this case:

- Disconnect the charger, wait a few seconds, and plug it in again.
- It may be necessary to repeat this several times.

Maintenance menu

This menu contains information that you could be asked for to perform specific operations. If they are required, you will be shown how to find information you need.

Warning

Certain chemical products can damage plastic. Do not use aerosols, certain special cleaning products, corrosive products, solvents, alcohol and detergents.

15. Upkeep

15. Upkeep



56

The use of your phone is controlled by safety regulations intended to protect both the user and his/her environment.



CE marking on the unit conforms to directives 1999/5/EC, 89/336/CEE and 73/23/CEE.

Electrical safety

Only use the appropriate chargers contained in the manufacturer's catalogue. Using another charger could be dangerous and will invalidate the manufacturer's warranty.

The main plug socket must be easily accessible.

The main voltage should correspond to that given on the manufacturer's plate on the charger.

16. Recommendations

16. Recommendations



Airplane safety

In an airplane, your phone must be switched off to ensure that it does not interfere with the planes systems. Its use is illegal and you could be prosecuted or banned from using cellular networks in the future if you do not abide by these regulations.

Areas containing combustibles

It is advisable to switch your phone off in the vicinity of gas stations.

Regulations limit the use of radio equipment in chemical factories, gas depots and any area where there are mines. You are advised to abide by these rules.

Road safety

Except in an emergency, do not use your phone when driving without a hands-free kit that enables you to maintain your freedom of movement. Always keep your eyes on the road when you are driving. To make a call, pull to the side of the road, then make your call. Abide by the current laws.

57

The phone must be shielded sufficiently from electronic equipment in the vehicle. It gives off micro-waves, which may affect the operation of such equipment.

- Installation of your phone in a vehicle must only be performed by qualified personnel.

Warning

Ensure that no part of your body is permanently close to the aerial unless there is a metal screen (e.g.: a vehicle roof, ...).

Non ionising radiation

- To obtain maximum satisfaction from your phone, use it in a vertical position. Your personal safety can only be improved by doing so.

Electronic medical equipment

- Your phone emits radio waves that could possible interfere with electronic medical equipment, for example an auditory prosthesis, heart pacemakers, ... Your doctor or the manufacturer of the medical item will be able to advise you on whether your phone could cause such interference.
- In hospitals, the phone must be switched off.

16. Recommendations



General precautions

- Do not attempt to open your phone and repair it yourself. The manufacturer cannot be held responsible for any damage/accident that may result from this.
- Any work carried out by non-authorised personnel will invalidate your warranty.
- Do not use your phone in damp areas (bathroom, swimming pool, ...). Protect it from water and other liquids.
- Do not expose your phone to extreme temperatures.
- Do not leave your phone within the reach of small children (certain removable parts may be accidentally ingested).
- Use your phone with original accessories, or your warranty will be rendered invalid.
- The physicochemical processes created by chargers impose temperature limits when charging the battery. Your phone automatically protects the batteries in extreme temperatures.
- Removing the battery may mean that the time is lost.

58

- You are strongly advised not to connect your phone to the charger if it doesn't contain a battery.
- To avoid the risk of demagnetisation, do not let electronic devices close to your phone for a long time.

Warning

The constructor cannot be held responsible if the above recommendations are not followed or if the phone is incorrectly used.

Note on downloading facilities

You can use your mobile phone to download ringing tones, icons and animated screen savers. Some of these items may contain data that causes your mobile phone to malfunction or to lose data (viruses for example).

Sagem declines all responsibility for (1) the reception of data that has been downloaded or loss of said data, (2) the consequences on the operation of the mobile phone and (3) damage resulting from the reception of said downloaded data or loss of said data. Moreover, Sagem draws attention to the fact that problems caused by the reception of downloaded data that does not comply with Sagem's specifications are not covered by the guarantee. Consequently, the cost of diagnosing and repairing mobile phones affected by said downloaded data will be charged to customers.

The software program developed by SAGEM remains the exclusive property of SAGEM SA. It is therefore highly prohibited to modify, translate, de-compile or disassemble this software program or any part thereof.

16. Recommendations



Answers to your questions

The telephone does not turn on

- Remove the battery and then replace it.
or
- Connect the phone to the charger (check that this is plugged in) for approximately 5 minutes.

No network recognised

- Remove the SIM card. Check that there is no dust or grit in the SIM slot. Replace the SIM card being sure to push it right up to the stop point.

Calls to a messaging service or voice server do not get through

- Check in the Ringing and beeps/Tones menu that the box is ticked.

Unable to turn the phone on

- Charge the phone for 15 minutes before turning it on.
Check the battery charging indicator:
cycling: charging normally



59

not cycling: disconnect the charger, re-connect and then check the battery charging indicator: if it is still not cycling, disconnect the charger and re-connect several times.

If the battery is still not charging, contact the after sales service.

When the battery charging indicator is continuously on, the battery is fully charged.

Error message: BATTERY STATUS NOT KNOWN

- The battery pack is not recognised by the phone. Check that the battery pack is correctly fitted in the phone.

Error message: LOW BATTERY

- This message is displayed when the battery charge is too low. The phone turns off automatically. Charge the phone.

Error message: SIM NOT PRESENT

- Check that the SIM card has been inserted correctly.



Answers to your questions





60

- Examine the SIM card. If it is damaged, contact your mobile phone operator sales point. If the message is still displayed, contact the after sales service.

Error message: INCORRECT PIN

- The PIN has been incorrectly entered. If the PIN is entered incorrectly three times, the SIM card is blocked.

Error message: SIM BLOCKED

- The PIN has been incorrectly entered three times. Use your Personal Unblocking Key (PUK) to unblock the SIM card.

Enter:

**05*PUK*PIN*PIN#

PUK: your PUK code supplied by your Operator.

PIN: your PIN code.

After 10 (or 5 depending on the type of SIM card) unsuccessful attempts, the SIM card is blocked permanently. You must then contact your Operator to get a new card.

Error message: SIM LOCKED

- The Operator may require certain types of SIM card to be used. This message indicates that the SIM card is not accepted.
- Remove the SIM card and turn the phone on again. If you get the SIM not present error message, check with your phone dealer whether your SIM card is compatible. Otherwise, contact the after sales service.

The phone display does not change

- Press a key. If nothing is displayed, check the position of the SIM card. If the problem continues, contact the after sales service.

No connection made

- Check the form of the number called.
- Check that there is at least one field strength dot showing. If R is displayed but there is no mobile phone operator name, only emergency calls are allowed.
- Check that you have not used all your credit with the mobile phone operator.
- Check that the SIM card provides the service you required and that it has not expired.



- Check and, if necessary, disable the outgoing call lock.
- The network is saturated. Please try later.
- If you still have problems getting a connection, contact the Hotline.

Unable to receive calls

- Try to make a call to check that the phone and the network are operational.
- Check and, if necessary, disable the permanent call redirection (permanent call redirection icon displayed).
- Check and, if necessary, disable the incoming call lock.
- If you still have problems receiving calls, contact the Hotline.

Cannot send messages

- Check that the SIM card provides this service.
- Check that the message server is correctly set up.
- Try to make a call to check that the phone and the network are operational.
- Try sending the message later.



61

No voice box

- Check that the SIM card provides this service.
- Set up the redirection to the voice box using the information provided by the Operator.

Answers to your questions



251108518



DATA SUBJECT TO CHANGE WITHOUT NOTICE

SAGEM SA
MOBILE PHONES DIVISION

Le Ponant de Paris - 27, rue Leblanc - 75512 PARIS CEDEX 15 - FRANCE
Public Limited Company with an Executive Board and a Supervisory Board
with capital of € 36,235,876 - 562 082 909 RCS PARIS

