



General Functions

Making a Call


When the idle screen is displayed, key in the area code and phone number and press .

Note: If you have set the **Auto Redial** option (6-7) to **ON** (see page 77) and the person called does not answer or is already on the phone, the number is redialled automatically up to ten times.


International Calls

1. Press and hold down the **0** key.
The + character appears.
2. Key in the country code, area code and phone number and press .

Correcting the Number

To clear...	Then...
The last digit displayed	Press the C key.
Any other digit in the number	Press the  soft key until the cursor (I) is immediately to the right of the digit to be cleared. Press the C key.
The whole display	Hold down the C key for more than one second.

Ending a Call

When you have finished your call, briefly press the  key.

Making a Call from the Phonebook


You can store the names and phone numbers called regularly in the SIM card and phone memory, called the phonebook. You then simply select the required name to recall the associated number. For further details on the Phonebook feature, refer to page 36.

Voice Dialling

If you have set the **Active Flip** option (6-0) to **ON** (see page 78), your phone also allows you to say a name when you open the flip cover. It then automatically dials the number stored with the name. For further details on the Voice Dialling feature, refer to page 42.

Last Number Redial

The phone stores the last 10 numbers dialled. To recall any of these numbers, proceed as follows.


1. If there are any characters on the display, clear the display by holding down the **C** key for more than one second.
2. Hold down  to display the last number dialled.

General Functions

- Use the ∇ soft key (or \blacktriangle or \blacktriangledown on the left side of the phone) to scroll through the numbers until the required number is displayed.
- Press \blacktriangle to dial the number displayed.

Adjusting the Volume

During a call, if you want to adjust the earpiece volume, use the volume keys on the left side of the phone. Press \blacktriangle to increase and \blacktriangledown to decrease the volume.




In idle mode with the flip cover open, you can adjust the key tone volume using the same keys.

General Functions

Answering a Call

When somebody calls you, the phone rings and the phone icon in the middle of the screen flashes.



If the caller can be identified, the caller's phone number (or name if stored in your phonebook) is displayed. If the caller cannot be identified, only the phone icon flashes.

- If necessary, open the flip cover.

Press \blacktriangle or the **Accept** soft key. If the **Any-key Answer** menu option (6-4) is set to **ON**, you can press any key to answer a call except for \blacktriangle and the **Reject** soft key (see page 75).

Note: To reject an incoming call, press the **Reject** soft key or \blacktriangledown . If the **Any-key Answer** menu option (6-4) is set to **OFF**, you can reject the call by pressing \blacktriangle or \blacktriangledown on the left side of the phone.

- End the call by closing the flip cover or pressing \blacktriangle .

Note: You can answer a call while using the phonebook or menu features.

Viewing Missed Calls

If you are unable to answer a call for any reason, you can find out who was calling you, if this service is available. In this way, you can call the person back, if necessary.

The number of missed calls is displayed on the idle screen immediately after the call was missed.

To view the missed call immediately, proceed as follows.

- | | |
|-----------------------------------|---------------------------------|
| 1. If the flip cover is... | Then... |
| Closed | Open the flip cover. |
| Open | Press the View soft key. |

The number corresponding to the most recent missed call is displayed, if available.

- | | |
|-------------------------------------|---|
| 2. To... | Then press the... |
| Scroll through the missed calls | ↵ soft key. |
| Call the number displayed | ☎ key. |
| Edit or delete a missed call number | Options soft key (see the following paragraphs). |

Editing a Missed Call Number

1. Press the **Options** soft key.
2. Press the **Select** soft key.
3. Change the number as required. Press the ↵ soft key to move back through the number.

- | | |
|------------------|--|
| 4. To... | Then press the... |
| Call the number | ☎ key. |
| Store the number | Save soft key and enter the name and location required (for further details, refer to page 36). |

Deleting a Missed Call

1. Press the **Options** soft key.
2. Press the ↵ soft key to highlight the **Delete** option.
3. Press the **Select** soft key.

You can press ☎ / 0 at any time to exit the Missed Call feature.

Note: You can access the Missed Call feature at any time by selecting the **Missed Calls** menu option (2-1); for further details, see page 60.